

## Flat PAR LED 18x3w RGB -IP20 (Indoor Use Only)

### DMX Control Channel Function

### DMX VALUE

Channel 1	DIMMER	R-G-B Fader	0-255
Channel 2	RED	RED Light	0-255
Channel 3	GREEN	GREEN Light	0-255
Channel 4	BLUE	BLUE Light	0-255
Channel 5	AUTO	Colors to Cascade	50-100 Jump Change 101-150 Pulse Change 151-200 Gradual Change 201-255 Sound Activated
Channel 6	SPEED	SPEED ADJ Slow to Fast	0-255

### Stand Alone Function – Display - Mode Settings (values are 0-255)

- r. \_\_\_ 0-255 Red Static Color
- g. \_\_\_ 0-255 Green Static Color
- b. \_\_\_ 0-255 Blue Static Color
- F. \_\_\_ 0-003 Lights Static
- d. \_\_\_ DMX-512 Setting Address (0-512) or Slave Serial
- P. \_\_\_ Jump Colors Change Mode
- L. \_\_\_ Pulse Colors Change Mode
- E. \_\_\_ Gradual Colors Change Mode
- soud Sound Activated

### 3-PIN DMX I/O Included Accessories

- PC – Pipe Clamp
- SC – Safety Cable
- YY – Double Yoke / Floor Stand

### AC Edison Plug 100-120v 54w

