

Firmware Version 2.4
April 2002



480C - 36 Avenue S.E.
Calgary, AB, T2G 1W4
Canada

Phone: (403) 243-8110

Fax: (403) 287-1281

E-mail: support@pathwayconnect.com
www.pathwayconnect.com

Table of Contents

About The DMX <i>Ultimate Converter</i>	4
Protocols Supported	4
Quick Start: Basic Conversion	5
Configuring Inputs	6
Input Terminator	6
Configuring Outputs	6
DMX Output	6
Speed	6
AMX Output	6
Reset	6
Colortran	6
AVAB	6
Channels	6
EC-Mux	6
Microplex	7
Kliegl	7
Start Address	7
6/12K Assignments (amx only)	7
AMX Start address	8
Configuration Memory	8
Diagnostics	9
Tweak Output	9
Analyze Input	9
User Options	9
Status Quo	9
About	10
Security	10
RS232 Link	10
Output Test	10

Updating your DMX <i>Ultimate</i> Converter	11
Update procedure	11
Software Update Troubleshooting Tips.....	12
Appendix A	13
Connector Pinouts	13
DMX512	13
Electro-Controls Mux (ECMux).....	13
Colortran Mux (CMX).....	13
AMX192 (XLR)	13
AMX192	14
Strand D54	14
MicroPlex	14
Kliegl K96	14
AVAB	14
Technical Support	15

ABOUT THE DMX ULTIMATE CONVERTER

Before the advent of the USITT DMX512 control signal standard, manufacturers developed a number of proprietary multiplex communications protocols. Strand developed AMX, Colortran had their CMX, Kliegl offered K96, and Electro Controls (also known as Control Lighting) used EC-Mux. Additional protocols also followed in the form of NSI's MicroPlex, Strand Europe's D54 and AVAB's own multiplex protocol.

We designed *DMX Ultimate Converter* to permit the interconnection of consoles and dimmers that employ different communications protocols. In addition, the *DMX Ultimate Converter* also provides other useful customization and diagnostic functions, all in a simple to learn and use device.

PROTOCOLS SUPPORTED

The *DMX Ultimate Converter* supports a wide range of lighting industry communication protocols. They are:

Protocol	Description	Connector
DMX512	Probably the most widely used protocol for controlling lighting equipment, DMX was the first USITT industry standard multiplex protocol. DMX generates up to 512 control signals.	5 pin XLR
AMX192	Originally Strand Lighting's first multiplex protocol, AMX is an analog multiplex protocol that carries up to 192 control signals. AMX192 is now a USITT standard.	4 pin XLR (also 4 pin mini TA4)
Colortran	Also referred to as CMX, Colortran's digital protocol was the forerunner of DMX512.	5 pin XLR
AVAB	The AVAB protocol was one of the early digital protocols. The AVAB protocol produces 240-252 control signals.	Variety
EC-MUX	Electro Controls' foray into digital dimmer control resulted in this 512-dimmer protocol. Commonly used with <i>Celebrity</i> control consoles. Strand Lighting later bought Electro Controls.	4 pin XLR
Kliegl	Kliegl made a wide range of consoles and dimmers prior to going out of business in the 80's. The Kliegl protocol is often referred to as K96, after the dimmer rack it was developed for. K96 is able to handle 10,000 dimmers on 480 control channels.	Variety
D54	Designed by Strand for their European dimmers and consoles, D54 produces 384 control signals.	3 pin XLR
MicroPlex	MicroPlex is a protocol developed by NSI to control their dimmers. It is also used by Lightronics. Limited support (48 channels output, no input) is offered for MicroPlex.	3 pin XLR

QUICK START: BASIC CONVERSION

Plug in the power cord to your *DMX Ultimate Converter*. The internal power supply will automatically sense and accommodate any voltage/frequency from 100-240VAC and 50/60 Hz. The *DMX Ultimate Converter* is configured using the arrow keypad to navigate the options provided on a helpful LCD menu display. The arrows at the end of each line show your options from that point in the menu. Use the OK button to make your selection.



NOTE: Not all menu functions shown on the display are supported by firmware versions earlier than 2.5. Only the items described in this manual are supported.

Since your *DMX Ultimate Converter* is capable of performing a number of different conversions, you will need to specify the conversion desired before you start. Use the ► button until you see the SELECT INPUT option, and then press the ▲ or ▼ button until you see the desired input protocol. Press OK. Select TERMINATED or UNTERMINATED INPUT if displayed (see below), and press OK again. Now press the ► button until you see the SELECT OUTPUT option, and again use the ▲ and ▼ buttons scroll through your output choices. Press OK when you find the desired output protocol. Your converter is now ready to process and convert your control protocols. Press the ► key until you see GO TO STATUS DISPLAY and press OK. The status display will show a number of messages pertaining to the current state of the converter. One of them will look something like:

```

INPUT      OUTPUT
A:DMX     C:AVAB
  
```

This indicates the conversion mode in effect and the ports (A to F) you should be connected to. You will also see something like:

```

CONVERSION MODE
DMX TO AVAB
  
```

This is provided as an additional, plain English indication of the selected conversion mode.

Some input protocols require termination when your *DMX Ultimate Converter* is the last device connected on a data line. For example, if *the DMX Ultimate Converter* is the only thing connected to the console DMX output, then it *is* the last device on that data line and should be terminated. Where appropriate, you will be offered the option of terminating the input line after you have selected the input protocol.

There are a number of additional optional parameters that can be set on your input and output protocols. These are discussed in the next section.

CONFIGURING INPUTS

INPUT TERMINATOR

When the *DMX Ultimate Converter* is the last device in a DMX, Kliegl, Colortran or AVAB daisy chain, it must be terminated in order to comply with wiring rules and to ensure reliable system operation.

When one of the above protocols is chosen from the Select Input menu, the current state of the DMX input terminator is shown. To change the current termination setting, use the ▲ and ▼ buttons to make your selection and then press OK. Note that when termination is on, the pass-thru connector (port B) is disabled.

CONFIGURING OUTPUTS

Different output protocols have different parameters and options. Use the following to help you select the right configuration options for your application. If the recommended configuration does not appear to work properly, try selecting a different option.

DMX OUTPUT

SPEED

- Fast
- Medium (*recommended*)
- Slow
- Custom

AMX OUTPUT

RESET

- Normal (*recommended*)
- Narrow
- Wide

COLORTRAN

No user settings are provided for CMX protocol. The *DMX Ultimate Converter* will communicate properly with most Colortran dimmers including D192 and ENR, as well as D/A converters.

AVAB

CHANNELS

AVAB systems can be configured for 240 or 252 channels. Use the AVAB channels configuration to use the minimum number of channels suitable for your system.

EC-MUX

No user settings are provided for ECMux protocol. The *DMX Ultimate Converter* will communicate properly with all EC QD-series digital dimmer racks, Strand/EC CD80AE (ECMux version) and QD dimmer packs.

MICROPLEX

There are two different types of Microplex protocol, Microplex 1 (NSI) or Microplex 2 (Lightronics). Choose the appropriate one for your application

KLIEGL

No user settings are provided for K96 output. The *DMX Ultimate Converter* will communicate properly with all K96 and K100 digital dimmer racks. These dimmer racks incorporate a channel/dimmer soft-patch function that must be assigned by the control console. The *DMX Ultimate Converter* deals with this by transmitting a 1-to-1-patch file once, each time a valid DMX signal is applied to its input (ie when the console is turned on or plugged in).

START ADDRESS

Use the Start Address setting to determine the start point of your output data (the default is 1). If you set a start address of 100, the information from channel one on your input protocol will appear on channel 100. The information from channel two on your input protocol will appear on channel 101, and so on.

6/12K ASSIGNMENTS (AMX ONLY)

Strand CD80® 6 and 12Kw dimmers occupy two AMX positions in the rack, so the output has to be adjusted accordingly. Use this function to identify which rack *slots* have 6 or 12K dimmer modules.

After you have selected AMX192 as an output protocol, use the ► button to locate

```

< 6/12K ASSIGN >
▲      AMX 1      ▼

```

6/12K assignments are made for each AMX output so they have to be defined for both AMX 1 and AMX 2. Use the ▼ button to select which AMX line you need to configure and press OK.

To change the existing 6/12K assignment select EDIT. You will see

```

SLOT#   TYPE
▲ 001 ▼ < 2K >

```

Use the ▲▼ arrow keys to first select the desired slot number for a 6 or 12K module, then use the ◀▶ keys to change the module type from 2K to 6/12K. When selected, use the ▲▼ keys to select the next slot, and so on. Do not press OK until you have finished your assignments.

You can also use the 6/12K-edit function to review what slots have which type of dimmer module.

**TIP!**

If the wrong dimmer responds to your AMX control, check the 6/12K assignments to make sure that they are correct.

To restore all slots to 2K (no offset), select SET DEFAULT, and press OK. Since this will overwrite any 6/12K assignments previously made, you are prompted for a YES to confirm. *There is no 'undo' once YES is selected.* If you do not want to go ahead with restoring the default setting, select NO and press OK.

AMX START ADDRESS

The *DMX Ultimate Converter* has been provided with two AMX output ports (E & F). The Start Address setting affects only to the second AMX port. A typical application would have AMX 1-192 on port E and AMX 193-384 on port F. In this configuration you would set the start address as 193.

CONFIGURATION MEMORY

The *DMX Ultimate Converter* stores all of its user-configured operating parameters in non-volatile Flash memory. This type of memory storage makes possible to leave the unit in a powered down state indefinitely with no loss of configuration data.

DIAGNOSTICS

Your *DMX Ultimate Converter* offers a number of powerful protocol tools that can help fine tune the output, or troubleshoot problems.

TWEAK OUTPUT

Tweak Output offers the user the ability to modify a number of DMX512 output timing parameters. This can be especially useful to customize the output to conform to the special requirements of some equipment. Start by selecting one of the three standard DMX speeds (fast, medium, slow) from the Select Output Menu, then select Tweak Output from the Diagnostics Menu. You can tweak any or any combination of, Break, Delay, or Mark (Mark-After-Break), by adjusting the value for each one. Adjust one value at a time until the correct operation of the DMX receiving device is observed. The resulting custom DMX speed can then be selected from the Select Output menu.



WARNING! *Adjusting the output parameters may result in an unusable signal. Use care when using Tweak Output. This function should only be used by someone who is versed in communications protocols. If problems arise, it is best to re-select one of the three standard DMX speeds from the Select Output Menu, and repeat the Tweak Output process.*

ANALYZE INPUT

Often, as a part of your troubleshooting process, you want to confirm that the console is providing the output that you think it is! Analyze Input allows you monitor the input of the *DMX Ultimate Converter* (the output from your console) one channel at a time.

```

◀ANALYZE INPUT ▶
CHAN▲001▼ LEV000
  
```

Use the ▲ or ▼ to select the channel you wish to monitor. The level will be displayed as a value from 1 to 255.

USER OPTIONS

User options allow you to configure your *DMX Ultimate Converter* to suit your preferences.

STATUS QUO

Status quo provides you with a safety net in the event the input data is interrupted. The input data could be interrupted, for example, if the control console were inadvertently turned off. With the status quo function enabled, your *DMX Ultimate Converter* will hold the last levels received before the data was interrupted. Those levels are held for a duration you specify. If the incoming data is not restored at the end of the status quo duration, the *DMX Ultimate Converter* will turn off its output.

The status quo current setting is shown when the status quo option is selected. To change the current setting, press OK. The status quo hold time is user selectable from 2 seconds up to 98 minutes. In addition, an infinite hold is available (NO END).

ABOUT

Use this menu item to determine the current software version running in the *DMX Ultimate Converter*. Check the Pathway Connectivity website periodically for updates.

SECURITY

There may be situations where you do not want the settings of the *DMX Ultimate Converter* modified. The security feature allows you to lock out users from modifying any *DMX Ultimate Converter* settings.

Select Security from the Users Options menu. The current state of the security lockout will be displayed.



To turn security on or off from this menu item, simply push and hold the OK button for approximately 2 seconds.



WARNING! This function is not intended to provide a high level of security. It is simply provided as a flag to users that settings should not be casually modified, or as a deterrent to unauthorized users.

RS232 LINK


The RS232 Link is used to update the *DMX Ultimate Converter* software. See 'Updating your *DMX Ultimate Converter*' later in this manual for operation instructions.

OUTPUT TEST

Output test allows the Ultimate to directly control individual channels regardless of input.



Press OK to enter Output Test mode.



Use the ◀▶ arrow keys to select the desired output channel, then use the ▲▼ keys to change the intensity from 1-255. Use the ◀▶ keys to select the next channel, and so on. Press OK when you wish to leave output test mode.



To quickly change a channel level from zero to full, rather than increasing the level with the ▲ key, press the ▼ key instead and the level will change to 255.

UPDATING YOUR DMX ULTIMATE CONVERTER

Features, enhancements and updates for your *DMX Ultimate Converter* are available from Pathway Connectivity 's website www.pathwayconnect.com.



WARNING! *This function should only be undertaken by a qualified service technician, versed in communications protocols. Contact the factory for operational details.*

UPDATE PROCEDURE

To upgrade the *DMX Ultimate Converter* to the latest firmware you will require the following:

- The update software package
- A serial cable – male 9-pin to either female 9-pin or male 25-pin depending on your PC. This must be a "straight thru" cable not a null modem cable.



DANGER!

There is a risk of electric shock while performing this procedure. Do not touch the circuit board with any object or body part with power applied. Be especially careful around the left circuit board, as this is the power supply board. This is a procedure for qualified personnel only.

1. Check the existing version of software in the Converter. To do this cycle through the menu to **USER OPTIONS**; Scroll down to **ABOUT** and press **OK**. Note the major version number – i.e. **V2.10** is version 2, **V1.80** is version 1.
2. Unplug the Converter power cable.
3. Remove the eight cover screws and the top cover and set aside.
4. Connect the male 9-pin end of the serial connector to the 9-pin female connector on the right side of the circuit board.
5. Connect the opposite end of the serial cable to the back of your PC – Note the Com port number.
6. Start the **UPDATE.BAT** file on the PC and enter the Com port number that the converter is connected to.
7. Enter the current version (1 or 2) as noted in step 1.
8. Press and hold the **OK** button on the front of the Converter while plugging in the power cable.
9. If the current version is version 2 skip to step 14.
10. This should bring up the 1.0 download utility on the PC. If not, see the troubleshooting tips below.
11. Type **L** **LOADERX2.HEX** and press **ENTER**. It will take about a minute to download the update.
12. Once the download is complete the converter should flash the display and error light.
13. Press **Ctrl-C** on the PC Keyboard to exit the Update utility.
14. After HyperTerminal loads, press the **OK** button on the converter. This should bring up the 2.0 download utility. If HyperTerminal does not load, see the troubleshooting tips below.
15. Type **L** to begin the download. A series of squares will begin to show up on the screen. Select the **Transfer Menu (ALT T)** then **Send File...**

16. Enter ULTIMATE.UPD as the file name and select Xmodem as the protocol. Click the **Send** button.
17. After the download is complete press **S** to start the converter. If the converter starts unplug the converter, remove the serial cable and replace the cover and screws.
18. Plug in the converter and verify that the correct conversion mode is shown on the status display. If not see *Troubleshooting Tips* that follow.
19. Check that the conversion **Start Address** is correct for your application (i.e. 001 for no offset)

SOFTWARE UPDATE TROUBLESHOOTING TIPS

Problem	Possible Solutions
No Download Screen	Check that the converter display is blank during the download Check the serial cable connections Try selecting the other com port in UPDATE.BAT
Converter doesn't display status after update	Unplug the converter and plug it back in. Retry the download procedure.
Converter doesn't convert protocols after update	Verify that the Start Address is correct. Verify all input and output protocol settings.
HyperTerminal does not load	Check that HyperTerminal is installed. If not, Install it from your Windows CD-ROM

APPENDIX A


CONNECTOR PINOUTS

The DMX Ultimate Converter has 6 ports labeled a-f representing the most common connector types and pin assignments found in lighting control equip. In certain cases (e.g. MicroPlex, Kliegl and AVAB) the connectors used by the manufacturers may differ from the connector type used on the ultimate Converter. Please use the information shown below to make any required adapters.


DMX512

DMX Pin assignment

- 1 – Common (shield)
- 2 – Data –
- 3 – Data +
- 4 – Aux Data -
- 5 – Aux Data +



OUT (F)
Port C




IN (M)
Port A


ELECTRO-CONTROLS MUX (ECMux)

ECMux 4/5 Pin assignment (output)

- 1 – Common (shield)
- 2 – Data –
- 3 – No Connection
- 4 – No Connection
- 5 – No Connection



OUT (F)
Port D




IN (M)
Port A


COLORTRAN MUX (CMX)

CMX Pin assignment

- 1 – Common (shield)
- 2 – Data –
- 3 – Data +
- 4 – No Connection
- 5 – No Connection



OUT (F)
Port C




IN (M)
Port A


AMX192 (XLR)

AMX XLR Pin assignment

- 1 – Common
- 2 – Clock +
- 3 – Analog
- 4 – Clock -



IN (F)
Port D



OUT (M)
Ports E & F

AMX192

[Mini TA4] [Reference only, not used on the Ultimate Converter]

AMX Mini TA4 Pin assignment


- 1 – Clock -
- 2 – Common
- 3 – Clock +
- 4 – Analog

STRAND D54


[model 8681 only]

Strand D54 Pin assignment

- 1 – Common
- 2 – No Connection
- 3 – Analog



OUT (F)
Port E




IN (M)
Port D

MICROPLEX

MicroPlex Pin assignment

- 1 – Common
- 2 – No Connection
- 3 – Analog
- 4 – No Connection




OUT (M)
Port E


KLIEGL K96

Kliegl K96 Pin assignment

- 1 – Common (shield)
- 2 – Data -
- 3 – Data +
- 4 – No Connection
- 5 – No Connection



OUT (F)
Port C




IN (M)
Port A

AVAB

Kliegl K96 Pin assignment

- 1 – Common (shield)
- 2 – Data -
- 3 – Data +
- 4 – Console present
- 5 – No Connection



OUT (F)
Port C



IN (M)
Port A

TECHNICAL SUPPORT

Your first contact for support should be the dealer that provided your *DMX Ultimate Converter*. However, you should also feel free to contact Pathway Technical Support if you need help.

9:00 - 5:00 (Mountain Time) Monday through Friday

+1 403-243-8110

support@pathwayconnect.com